



# APPLICATION GUIDE

Make / Model	Year	NUMBER OF BUTTONS ON FRONT					Make / Model	Year	NUMBER OF BUTTONS ON FRONT					
		2	3	4	5	6			2	3	4	5	6	
<b>BUICK</b>						<b>GMC</b>								
Century / Regal	03-05		110300	110400			Taurus	98-05		210301	210400			
Lacrosse	06-09			110407	110507		Thunderbird	02-05		210301	210400			
Lesabre / Park Ave	96-05			110400			Windstar	99-05		210301	210400			
Lucerne	06-09			110408	110508		<b>GMC</b>							
Rainer	04-08		110304				Acadia	08-09			110418	110508	110608	
Rendezvous	02-08			110406			Canyon	05-09		110306				
Terrazza	06-08				110506		Envoy	04-09		110304				
<b>CADILLAC</b>						<b>GMC</b>								
CTS / CTS-V	04-07		110303	110403			S15 Sonoma	01-04		110300				
Escalade	2002		110300				Sierra	95-99	110205	110305				
	03-06		110302					99-02		110300				
Not 08-09 Larger Key Fob	07-08			110418	110508	110608		03-06		110302				
Sedan Deville	98-05			110400			w/o Remote Start	07-09		110308	110408			
	06-08			110408	110508		w/ Remote Start	07-09			110418			
SRX	04-08		110303	110403			Yukon / Yukon XL / Denali	95-99	110205	110305				
STS	01-05			110400				00-02		110300				
	06-08			110408	610506			03-06		110302				
XLR	05-08				610506		w/ Remote Start	07-09			110418	110508	110608	
<b>CHEVROLET</b>						<b>HUMMER</b>								
Astro	01-05		110300	110400			H2	03-07		110302				
Avalanche	2002		110300					with remote start	08-09			110418		
	03-06		110302				H3	06-09		110306				
w/remote start	07-09			110308	110408		<b>LINCOLN</b>							
Camaro	96-02		110305	110403			Aviator	03-07			210400			
Cavalier / Sunfire	00-05			110403			LS	00-06		210301	210400			
Cobalt	05-09			110407	110507		Navigator	98-09			210400			
Colorado	04-09		110306				Town Car	98-07			210400			
Corvette	01-05			110400			<b>MERCURY</b>							
	06-08			710406			Grand Marquis	03-09			210400			
Equinox	05-06		110302				Mountaineer	99-09			210400			
with remote start	07-09		110308	110418	110508		Sable	98-05		210301	210400			
Express	05-09			110400			Tribute	01-09		210300				
HHR	06-09			110417	110507		<b>NISSAN</b>							
Impala	00-05			110400			350Z	03-09		510304	510404			
	06-09			110408	110508		Altima	04-09		510304	510404			
Malibu	00-03			110400						510304 or 510307	510404			
	04-07			110407	110508		Armada	04-09		510304 or 510307	510404			
Monte Carlo	00-05			110400			Frontier	99-09		510304 or 510307	510404			
	06-09			110408	110508		Maxima	04-09		510304	510404			
S-10 / Sonoma / Blazer	98-04		110300	110400			Murano	03-09		510304	510404			
Silverado	95-99	110205	110305				Quest	02-09		510304	510404			
	99-02		110300				Pathfinder	99-09		510304 or 510307	510404			
	03-06		110302				Sentra	03-09		510304	510404			
without remote start	07-09		110308	110408			Titan	04-09		510304	510404			
with remote start	07-09			110418			Xterra	03-09		510304 or 510307	510404			
SSR	03-06			110400			<b>PONTIAC</b>							
Suburban / Tahoe	95-99	110205	110305				Aztek	01-07			110406			
	00-02		110300	110400			Bonneville	03-05			110400			
	03-06		110302				Grand AM	98-05		110305	110400			
without remote start	07-09			110408	110508	110608	G6	05-09			110407	110507		
with remote start	07-09			110418			Grand Prix / Intrigue	99-03			110406			
TrailBlazer	02-09		110304					2004			110400			
<b>CHRYSLER / DODGE / JEEP</b>						<b>PONTIAC</b>								
Caravan	99-05		310301	310401			Montana	05-06			110407	110507	110506	
Dakota	99-04		310301				Solstice	07-09			110407			
Durango	99-03		310301	310401			Torrent (See Equinox)	06-07		110302				
PT Cruiser	01-05		310301	310401			Vibe	04-09		410300				
Ram 1500 2500 3500	98-05		310301				<b>SATURN</b>							
Jeep Grand Cherokee	00-04		310301	310401			AURA	07-09			110407	110507		
Jeep Liberty	02-05		310301	310401			ION	04-09			110400			
Jeep Classic	00-04		310301	310401			Relay	05-09				110506		
<b>FORD</b>						<b>TOYOTA / SCION</b>								
500	05-07			210400			Sky	07-09			110407	110507		
Escape	01-09		210300	210400			VUE	03-07		110302				
Escort	98-02		210301				w/ Remote Start	08-09			110418	110508		
Excursion							<b>TOYOTA / SCION</b>							
Battery in back cover	00-06		210300	210400			Avalon	99-05		410300	410406			
Battery mounted to board	00-06		210301					06-07			410406			
Expedition	99-09		210300	210400			Camry / Solara	99-05		410300	410406			
Explorer	99-09		210300	210400			Corolla	99-09	410201	410300				
F150							FJ	07-09	410201					
Battery in back cover	97-09	210200	210300				4 Runner	00-09	410201		410406			
Battery mounted to board	01-09		210301				Highland	01-09	410201		410406			
F250 / F350							Prius	01-09	410201					
Battery in back cover	99-09	210200	210300				Rav4	99-09	410201		410406			
Battery mounted to board	01-09		210301				Sequoia	01-09	410201		410406			
Focus	99-07		210300	210400			Sienna	99-09	410201		410406			
Freestyle	05-07		210300	210400			Tacoma	99-09	410201	410306				
Mustang	99-09		210300	210400			Tundra	00-09	410201	410306				
Ranger	99-09	210200	210300				tC	05-09	410201					
							xA	04-09	410201					
							Xb	04-09	410201					

\$24.95 Each MAP

Part Numbers are 8 numbers. Add the Design number to the end of the part number for a complete part number. Example 210200 08 is Mossy Oak Camo

Design Chart: 01-Black CF 02-Silver CF 03-Leopard 04-Flag 05-PigSkin 06- Burlwood 08-Mossy Oak  
09-Pink CF 10- Zebra 11-Blue CF 12-Red CF 13-Orange CF 14- Clear 15- \$100 Bills